

WEST VIRGINIA EROSION AND SEDIMENT CONTROL





Triple Rig













Permit Application Requirements

- Site Construction Plan: For sites 3 ac. or more disturbed, excluding pipelines and roads, plans must be certified by a registered engineer.
- Includes a vicinity map locating the site in relation to the surrounding area and roads.
- Plan view of site on a scale of (1"-100') or greater, that provides existing topographic information on a contour interval that affords sufficient detail.
- Identifies proposed cut and fill areas with slope ratios.
- Includes cross-sections of length and width of the location with cut and fill volumes.

Permit Application Requirements

- Erosion and Sediment Control Plan: Over 3 acres disturbed , excluding pipelines and roads, plans must be certified by registered engineer.
- Contain a narrative and set of drawings.
- The narrative must describe a general sequence of events, how and when each construction phase (clearing and grubbing etc.) will occur and describe stabilization methods to be used and timeframes of usage.
- The plan view drawings show the location of all proposed erosion and sediment control BMP'S on a scale of (1"-100') or greater .

Sediment controls



Site Construction Criteria:

- Clear all woody material, brush, and trees from the site keeping clearing to the minimum necessary for construction.
- Topsoil shall be removed from construction areas and stockpiled for reuse during reclamation.
- Fill material shall be clean mineral soil, free of roots, stumps, sod, large rocks, frozen soil etc.
- Fill material will be placed in lifts over the entire length of the fill. Lift thickness shall be as thin as the suitable random excavated material will allow, typically from 6 to 12 inches.
- Each lift shall be compacted to a standard proctor density of at least 95% by compaction equipment .
- At the base of a fill slope a toe foundation will be constructed, and with each (50) vertical feet of slope a terraced bench shall be constructed.

Location Construction



Bench @ 50' Elevation Change



Road Construction



Rock Checks Water Control



Seeding

- Temporary seed where exposed soil is not to be worked for periods longer than 21 days or as soon as any finish dirt work is completed.
- Soil preparation is key to good grass cover. Seedbed must be loose at the time of seeding, disk or track to loosen.
- If seedbed preparation is not feasible add 50% more seed to the recommended mixture.
- Test soil , apply lime to bring soil pH to a suitable range (pH 6.0) for the planned seed species. In absence of a soils test, 3 tons / acre of lime may be applied.
- When reseeding the drilling site, roadway, etc., work with adjacent landowners and try to use a seed mixture that would be compatible with adjacent grasslands.
- At the base of a fill slope a toe foundation will be constructed, and with each (50) vertical feet of slope a terraced bench shall be constructed.

Hydroseeding



Sediment Control @ Culvert Outfall



