

---

## 5.9 Conductivity

### ***What is conductivity and why is it important?***

Conductivity is a measure of the ability of water to pass an electrical current. Conductivity in water is affected by the presence of inorganic dissolved solids such as chloride, nitrate, sulfate, and phosphate anions (ions that carry a negative charge) or sodium, magnesium, calcium, iron, and aluminum cations (ions that carry a positive charge). Organic compounds like oil, phenol, alcohol, and sugar do not conduct electrical current very well and therefore have a low conductivity when in water. Conductivity is also affected by temperature: the warmer the water, the higher the conductivity. For this reason, conductivity is reported as conductivity at 25 degrees Celsius (25 °C).

Conductivity in streams and rivers is affected primarily by the geology of the area through which the water flows. Streams that run through areas with granite bedrock tend to have lower conductivity because granite is composed of more inert materials that do not ionize (dissolve into ionic components) when washed into the water. On the other hand, streams that run through areas with clay soils tend to have higher conductivity because of the presence of materials that ionize when washed into the water. Ground water inflows can have the same effects depending on the bedrock they flow through.

Discharges to streams can change the conductivity depending on their make-up. A failing sewage system would raise the conductivity because of the presence of chloride, phosphate, and nitrate; an oil spill would lower the conductivity.

The basic unit of measurement of conductivity is the mho or siemens. Conductivity is measured in micromhos per centimeter ( $\mu\text{mhos/cm}$ ) or microsiemens per centimeter ( $\mu\text{s/cm}$ ). Distilled water has a conductivity in the range of 0.5 to 3  $\mu\text{mhos/cm}$ . The conductivity of rivers in the United States generally ranges from 50 to 1500  $\mu\text{mhos/cm}$ . Studies of inland fresh waters indicate that streams supporting good mixed fisheries have a range between 150 and 500  $\mu\text{mhos/cm}$ . Conductivity outside this range could indicate that the water is not suitable for certain species of fish or macroinvertebrates. Industrial waters can range as high as 10,000  $\mu\text{mhos/cm}$ .

### ***Sampling and equipment Considerations***

Conductivity is useful as a general measure of stream water quality. Each stream tends to have a relatively constant range of conductivity that, once established, can be used as a baseline for comparison with regular conductivity measurements. Significant changes in conductivity could then be an indicator that a discharge or some other source of pollution has entered a stream.

Conductivity is measured with a probe and a meter. Voltage is applied between two electrodes in a probe immersed in the sample water. The drop in voltage caused by the resistance of the water is used to calculate the conductivity per centimeter. The meter converts the probe measurement to micromhos per centimeter and displays the result for the user. NOTE: Some conductivity meters can also be used to test for total dissolved solids and salinity. The total dissolved solids concentration in milligrams per liter (mg/L) can also be calculated by multiplying the conductivity result by a factor between 0.55 and 0.9, which is empirically determined (see Standard Methods #2510, APHA 1992).

Suitable conductivity meters cost about \$350. Meters in this price range should also measure temperature and automatically compensate for temperature in the conductivity reading. Conductivity can be measured in the field or the lab. In most cases, it is probably better if the samples are collected in the field and taken to a lab for testing. In this way several teams of volunteers can collect samples simultaneously. If it is important to test in the field, meters designed for field use can be obtained for around the same cost mentioned above.

If samples will be collected in the field for later measurement, the sample bottle should be a glass or polyethylene bottle that has been washed in phosphate-free detergent and rinsed thoroughly with both tap and distilled water. Factory-prepared Whirl-pak® bags may be used.

### ***How to sample***

The procedures for collecting samples and analyzing conductivity consist of the following tasks:

#### **TASK 1** Prepare the sample containers

If factory-sealed, disposable Whirl-pak® bags are used for sampling, no preparation is needed. Reused sample containers (and all glassware used in this procedure) must be cleaned before the first run and after each sampling run by following Method A as described on page 128.

#### **TASK 2** Prepare before leaving for the sampling site

Refer to pages 19-21 for details on confirming sampling date and time, safety considerations, checking supplies, and checking weather and directions. In addition to the standard sampling equipment and apparel, when sampling for conductivity, include the following equipment:

- Conductivity meter and probe (if testing conductivity in the field)
- Conductivity standard appropriate for the range typical of the stream
- Data sheet for conductivity to record results

Be sure to let someone know where you are going and when you expect to return.

#### **TASK 3** Collect the sample (if samples will be tested in the lab)

Refer to page 128 for details on how to collect water samples using screw-cap bottles or Whirl-pak® bags.

#### **TASK 4** Analyze the sample (field or lab)

The following procedure applies to field or lab use of the conductivity meter.

1. Prepare the conductivity meter for use according to the manufacturer's directions.
2. Use a conductivity standard solution (usually potassium chloride or sodium chloride) to calibrate the meter for the range that you will be measuring. The manufacturer's directions should describe the preparation procedures for the standard solution.
3. Rinse the probe with distilled or deionized water.
4. Select the appropriate range beginning with the highest range and working down. Read the conductivity of the water sample. If the reading is in the lower 10 percent of the range, switch to the next lower range. If the conductivity of the sample exceeds the range of the instrument, you may dilute the sample. Be sure to perform the dilution according to the manufacturer's directions because the dilution might not have a

simple linear relationship to the conductivity.

5. Rinse the probe with distilled or deionized water and repeat step 4 until finished.

#### **TASK 5**

**Return the samples and the field data sheets to the lab/drop-off point.**

Samples that are sent to a lab for conductivity analysis must be tested within 28 days of collection. Keep the samples on ice or refrigerated.

#### **References**

- APHA. 1992. *Standard methods for the examination of water and wastewater*. 18th ed. American Public Health Association, Washington, DC.
- Hach Company. 1992. *Hach water analysis handbook*. 2nd ed. Loveland, CO.
- Mississippi Headwaters River Watch. 1991. *Water quality procedures*. Mississippi Headwaters Board. March.